


Alcuin JCR

TV

To control the LCD television, press the front fascia.....for the appropriate function.

HDMI and VGA cables are available; use the “input” function to switch between these and freeview.

Once the power button has been pressed, the other buttons will light.



Press the power symbol.

Projector

The projection screen can be lowered by the rocker switch found on the white dado trunking. The projector can be turned on by using the remote control available from Alcuin Porters.

A VGA cable is available, this is labelled “projector RGB”. It can be shown on the projector by setting its input to “RGB”.

The Yamaha amplifier controls what’s shown on the input of the projector called “Video”. Refer to the labels on the amplifier for what setting to use for each device.

The PS3 and Wii are permanently wired through the amplifier, as is a minijack cable for music players or laptop audio.

DVDs can be played by using the PS3.