


▪Collect infra-red Remote Control from Porters Desk
(please return after lecture)

▪Switch Projector On..... ①
(It will take a few seconds to automatically align
the slide transport mechanism to the zero position)



▪Before placing the slide magazine onto the projector, check that
the baseplate on magazine is locked into the zero-position

▪Put the loaded magazine onto the projector ensuring that the cleft in the slide magazine fits on to
the notch of the transport ring (see diagram)

Use Kodak 80 slide capacity magazine only

▪Press Slide forward button..... ②
(the first slide should appear on screen)


▪Focusing may be needed, therefore press either
refocus button..... ③

▪Press slide backward button ④

▪Stand-by button ⑤ allows you to turn projector
on/off during your presentation.
The slide magazine remains in position


▪Removing magazine.

Always return slide magazine to zero position,
where it can be simply lifted off the projector.
This is achieved by holding down slide change
button ② (forwards) or ④ (backwards) until
the magazine stops rotating



Note: The light shutter will open only when there is a slide in the gate,
therefore it is not necessary to use blank slides

Lamp failure: This projector is fitted with twin lamps,
should the projection lamp fail, the system automatically
activates the second projection lamp



If you require assistance, please contact an
Audio Visual Technician on extn 3036